Setting STD48 Digital Timer to Minute Mode

Description



1- Hold "Mode" and "down arrow" key simultaneously for 5 seconds until "tyP" is indicated on the screen. Then release the keys. KMAKINA



2- Push "Mode" key for some times until you see "toF" on the screen.

3- Using "up" and "down" arrow keys you can change the type of the timer. Timer types are as below:

	S.	Tenth of second
	S	Seconds
Parameter	ā.	Tenth of Minute
Fob	ō	Minute
	Н.	Tenth of Hour
	Н	Hour

Category

1. How to Use