
Installation and Connection to DTCOM Software

Description

- Download DTCOM


DTCOM Download

- Click on DTCOM_E.exe




AHP PLASTIK MAKINA

- Select COM port (Refer to COM port driver installation guide) and then click on â€œAuto Detectâ€•.



- After detection of some controllers, in the â€œcommunication protolâ€• section click on one the detected items and then click â€œSETâ€• then â€œCloseâ€•.








- Click on Monitor Icon.




- Select proper â€œAddressâ€•. In hydrostatic pressure testers from AHP, there are â€œnumber of lines+1â€• station address, for example in 4 station hydrostatic unit there are 5 address. 1 to 4 is related to pressure lines and 5 is related to temperature address. Select requested address for calibration.
- For DSC-OIT tester there are 2 address, 1 & 2 . Selecting each of these numbers will connect DTCOM to sensor 1 and 2.

AHP PLASTIK MAKINA





- In the bottom of page settings for the requested station address will be shown.





Calibration offset value. Be noted after set of proper value donâ€™t forget to â€œENTERâ€•. Unless the value will not be saved.

- Donâ€™t change any other parameters of this page.

Category

1. Software Guide

AHP PLASTIK MAKINA